



CNC Syntax Editor
Making Your Life Easier
PRINTED MANUAL

Advanced Serial Data Logger

© 2004-2016 AGG Software

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: 2016

Publisher

AGG Software

Production

© 2004-2016 AGG Software

<http://www.aggsoft.com>

Table of Contents

Part 1 Introduction	1
1 About software	1
2 Glossary	2
Part 2 License, Registration and technical support	4
1 License	4
2 Limitations	5
3 How to register	6
4 Support	6
Part 3 Installation	6
1 System requirements	6
2 Installation process	6
Part 4 Configuration	7
1 Introduction	7
2 Configuring properties	9
Part 5 Interface	12
1 Introduction	12
2 Key mapping	13
3 File menu	14
4 Edit menu	17
5 Search menu	20
6 Bookmarks	22
7 View menu	23
8 Tools Menu	23
Code repository	23
Lines numbering	25
Shift/Scale/Mirror	26
Exchange axes	28
Add and remove spaces	28
Compare file with WinDiff	29
Change characters case	29
Adjusting spindle speed and feed rate	29
Rotate	30
Find XYZ ranges	31
9 Windows menu	32

1 Introduction

1.1 About software

These days, digital technologies are coming into use in almost every area of our life. High precision of machine-controlled operations coupled with extended overall reliability ensure optimum result. Almost everything from photos to financial reports becomes digital.

However, some areas of process automation are somewhat neglected. Despite the fact, numeric control devices are an older technology than digital photography, there are not enough quality software solutions allowing NC editing.

I bet, you can easily name several all-inclusive photo editing tools, while it is really a problem to find good low-cost CNC editing software. Will the situation ever change?

It has already! Introducing CNC Syntax Editor by AGG Software, the unique feature-packed NC editing software, allowing full control over your program file.

CNC Syntax Editor operates as a multiple windows NC programming environment allowing for edit, change, upload and download programs to numerically controlled device. The application is capable of all types of ASCII CNC files and G codes, ensuring optimum performance even on those larger files.

CNC Syntax Editor can highlight a program syntax: commands, coordinates etc, visually splits commands and coordinates into groups, that help you to develop NC programs. Due to highly configurable options it is possible to set CNC Syntax Editor up the way which suits best for your editor needs.

Another great feature of CNC Syntax Editor is the set of built-in tools. Thanks to set it is possible to mirror you coordinates, shift or scale axes value, switch axes etc.

CNC Syntax Editor is a tool for writing and editing of Computer Numerical Control (CNC) programs. It has a comfortable and intuitive interface both for beginners and advanced programmers. CNC Syntax Editor is deceptively simple, but it is really a very powerful tool. The size and number of documents open at any one time is limited only by the amount of available Windows memory.

While most of the menu commands are common to many text editors, the "Tools" menu is useful for a CNC programmer to simplify tasks such as scaling, mirroring and renumbering blocks of code. Syntax colouring of text helps make the code easier to read, as does the ability to quickly insert spaces before words. The spaces can also be quickly removed so as to shrink the size of large files.

The ability to open multiple documents at one time enables the user to copy text from one file to another, merge files into one, or just look up an older program to help get the code format for a particular application.

In this manual the terms "document", "file", and "text file" refer to the text files that contain the CNC program.

DISCLAIMER:

The producers of this software have no control over how the software is used, how the user writes CNC programs or sets up the CNC machines; therefore we take no responsibility for any damage or

injury caused by files written or edited with this software.

As the user has twenty one days to try this software with the full function demo version, warranty is limited to replacement of defective product.

For more information, to report bugs, or to make suggestions please see our website at www.aggsoft.com, or email support@aggsoft.com.

Company home page: <http://www.aggsoft.com/>

Software home page: <http://www.aggsoft.com/cnc-edit.htm>

Serial port hardware reference: <http://www.aggsoft.com/rs232-pinout-cable/>

1.2 Glossary

Baud Rate - The transmission speed of data through an asynchronous channel. Often confused with BPS (bits per second), baud rate actually refers to the number of signals per second. Because each signal can represent more than one bit of data, the number of bits per second is usually higher than the baud rate. For example, 2400 bps is typically sent at a rate of 600 baud.

Binary File - A file that contains data or program instructions written in ASCII and extended ASCII characters.

ASCII - An acronym for American Standard Code for Information Interchange. ASCII files are plain, unformatted text files that are understood by virtually any computer. Windows Notepad and virtually any word processor can read and create ASCII files. ASCII files usually have the extension .TXT (e.g., README.TXT).

Bytes - A collection of eight bits that represent a character, letter or punctuation mark.

COM port - Short for a serial communication port. Most DNC software communicate with a computer through a communication port, and most IBM and IBM-compatible computers support up to four serial ports COM1, COM2, COM3 and COM4. Additional ports can be added by adding additional hardware.

CNC - Computerized Numerical Control Refers to machine tools that have a computer and memory to control their operation. Most all non manual machine tools sold today will be CNC. see also NC.

Data bits - A group of bits (1's and 0's) that represent a single character or byte. Typically, there are seven or eight data bits. During an asynchronous communication (e.g., BitCom connecting to CompuServe), each side must agree on the number of data bits. Data bits are preceded by a start bit and followed by an optional parity bit and one or more stop bits.

DNC – Acronym that can mean Distributed Numerical Control or Direct Numerical Control depending upon the application. In the beginning DNC stood for Direct Numerical Control. A computer provided machine instructions for a NC milling machine that were transmitted over telephone lines. Later the term DNC evolved to mean a system where a group of CNC machines are linked to a central computer. Or conversely a combination of computers are each linked to one or more CNC machines and the computers are linked together by way of a local area network. Distributed Numerical Control where by NC programs are sent (distributed) to the memory of a CNC machine. The program is then

run from the CNC memory.

Flow control - A method of controlling the amount of data that two devices exchange. In data communications, flow control prevents one modem from "flooding" the other with data. If data comes in faster than it can be processed, the receiving side stores the data in a buffer. When the buffer is nearly full, the receiving side signals the sending side to stop until the buffer has space again. Between hardware (such as your modem and your computer), hardware flow control is used; between modems, software flow control is used.

Handshaking - Is the way in which the data flow between computers/hardware is regulated and controlled. Two distinct kinds of handshaking are described: Software Handshaking and Hardware Handshaking. An important distinction between the kinds of signals of the interface is between data signals and control signals. Data signals are simply the pins which actually transmit and receive the characters, while control signals are everything else.

NC - Numerical Control The operation of a machine by a series of coded instruction's that consist of numbers and letters of the alphabet and other symbols. These are translated into pulses of electrical current or other output signals that active motors and other device to run the machine. On early NC machines these signals was often delivered to the machines by using punched tape. Also, the term NC machine refers to machine tools that do not have a computer and memory installed. see also CNC.

NC File – a file containing one or more programs in the special language for Numeric Control machines.

NC Program – a set of instructions written in the machine language and saved to an NC file.

Parity - In data communications, parity is a simple procedure of checking the integrity of transmitted data. The most common type of parity is Even, in which the number of 1's in a byte of data add up to an even number, and None, in which a parity bit is not added.

PC - abbreviation for a Personal Computer.

Punch - CNC output device - used in CNC machines to output programs to perforated tape. Units can be parallel to tape punch or serial output.

RS232, RS423, RS422 AND RS485 - The Electronics Industry Association (EIA) has produced standards for RS232, RS423, RS422, and RS485 that deal with data communications. EIA standards where previously marked with the prefix "RS" to indicate the recommended standard. Presently, the standards are now generally indicated as "EIA" standards to identify the standards organization.

Electronic data communications will generally fall into two broad categories: single-ended and differential. RS232 (single-ended) was introduced in 1962. RS232 has remained widely used, especially with CNC control builders. The specification allows for data transmission from one transmitter to one receiver at relatively slow data rates (up to 20K bits/second) and short distances (up to 50' @ the maximum data rate). This 50' limitation can usually be exceeded to distances of 200' or more by using low capacitance cable and keeping the data rates down to 9600 baud and lower.

RTS/CTS Hardware handshaking - uses additional wires to tell a sending device when to stop or start sending data. DTR and RTS refer to these Hardware handshaking lines. you can select whether

you need to use DTR or RTS individually, or use both lines for hardware handshaking. See also Xon/Xoff.

Stop bits - In data communication, one or two bits used to mark the end of a byte (or character). At least one stop bit is always sent.

Upload - To send one or more files from your computer's disk storage to a remote computer. In DNC this usually means from the CNC machine's control back to the DNC computer. This can also mean from your computer's disk to a remote computer, such as another PC or an online service or the internet.

2 License, Registration and technical support

2.1 License

Copyright © 1999-2016 AGG Software.
All Rights Reserved

SOFTWARE LICENSE

Trial Limited Version

The trial limited version of this software may be used for evaluation purposes at the user's own risk for a trial period. At the end of the trial period, the user must either purchase a license to continue using the software, or remove it from his/her system.

The trial limited version may be freely distributed, provided the distribution package is not modified. No person or company may charge a fee for the distribution of Advanced Serial Data Logger without written permission from the copyright holder.

Licensed Version

On payment of the appropriate license fee, the user is granted a non-exclusive license to use Advanced Serial Data Logger on one computer (i.e. a single CPU), for any legal purpose, at a time. The registered software may not be rented or leased, but may be permanently transferred, if the person receiving it agrees to terms of this license. If the software is an update, the transfer must include the update and all previous versions.

Registered customer are entitled to free updates during one year from the date of purchase. It means that during one year you can download and install the latest registered versions of Advanced Serial Data Logger from our site. If you don't want to purchase an updates, you can use the program forever; it will never expire, but you won't be able to use the latest version. If you purchased the software more than one year ago, you are no longer entitled to free upgrade and technical support; however, you can purchase an updates to the latest version at a special, greatly discounted price, and this updates will allow you to have free updates and technical support for another year. The type of update license must match the type of your existing license.

Whilst every care has been taken in the construction and testing of this software, it is supplied subject to the condition that the user undertakes to evaluate the suitability of the control for his/her purposes. AGG Software makes no representation of the software's suitability for any purpose, and the user agrees that AGG Software has no responsibility for any loss or damage occasioned by the use of this software.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE SOFTWARE AND DOCUMENTATION ARE PROVIDED "AS IS" AND AGG SOFTWARE DISCLAIMS ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, CONFORMANCE WITH DESCRIPTION, TITLE AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL AGG SOFTWARE BE LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL OR EXEMPLARY DAMAGES OR LOST PROFITS WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE PRODUCT, EVEN IF AGG SOFTWARE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, AGG SOFTWARE'S CUMULATIVE AND ENTIRE LIABILITY TO YOU OR ANY OTHER PARTY FOR ANY LOSS OR DAMAGES RESULTING FROM ANY CLAIMS, DEMANDS OR ACTIONS ARISING OUT OF OR RELATING TO THIS AGREEMENT SHALL NOT EXCEED THE PURCHASE PRICE PAID FOR THIS LICENSE.

Should any term of these terms and conditions be declared void or unenforceable by any court of competent jurisdiction, such declaration shall have no effect on the remaining terms hereof.

If you do not agree to these conditions you should not install this software.

2.2 Limitations

Program is distributed on shareware terms. This means limited and unavailable secondary program possibilities, which become valuable or available after program registration. To register the program read [here](#).

In trial version of our program are the following limits:

- Trial period is limited by 21 days. After that time program won't work until it is registered.
- Continuous program work time is limited. After set period a message will be displayed and program stops its work;
- All data export modules can handle first 100 records only;

2.3 How to register

The program is distributed on shareware terms. This signifies limited or unavailable many features of the program, getting of full value or available after program registration.

If you'd like to be a registered user, to get information about the release of new versions, to use technical support and, at last, to get access to disabled functions of the program, register your copy. For registration, please, read [license agreement](#).

If you want to buy a program through the Internet visit the [registration page](#) of our site. On this page you can get the newest information about the registration process, and also find an order link. After you've have the form of order registration. Enter your personal information and choose the most convenient payment method for you. Further, you'll get notification and follow the notes in it.

More information about services, registration documents, payment means you can get on our [registration page](#) of our site.

2.4 Support

Technical questions	support@aggsoft.com
Common questions	info@aggsoft.com
Sales questions	sales@aggsoft.com

3 Installation

3.1 System requirements

Windows 2000 Professional - Windows 10, including x64 and x86 OS, Workstation and Server OS.

3.2 Installation process

If any beta-version was installed on your computer, remove it.

Quit of the working Advanced Serial Data Logger on installation time.

Run an installation file.

By default, Advanced Serial Data Logger will be installed to the directory "C:\Programs Files\Advanced Serial Data Logger" or "C:\Programs Files (x86)\Advanced Serial Data Logger" of your system disk, but you can change this path.

In the standard distributive of Advanced Serial Data Logger are no additional modules files, which you can download from our [site](#).

4 Configuration

4.1 Introduction

Highlights

- Customizable Syntax Highlighting;
- Customizable code snippets;
- Search and Replace feature;
- Can upload programs to a NC with help of DNC Precision;
- Super comfortable editor with savable bookmarks;
- CNC specific tools: scaling, mirroring, lines numbering etc.
- Windows XP-styled interface;
- MDI interface that supports multiple windows;
- Windows/Unix/Mac line endings support.

Once the program is launched, the main program window is opened (fig.1). It is the editor environment. This image below shows the CNC Syntax Editor screen with its various parts labeled.

1. **Menu bar** - Menus are described in the Menus section of this help file;
2. **Editor toolbar** - contains button for quick access to the editor functions;
3. **Tools toolbar** - contains button for quick access to the set of CNC programmer's tools;
4. **Editor window** - the place for editing your programs. A **Title bar** of this window shows the file name of documents opened. If your document is modified, then title bar contains the "*" character after a file name;
6. **Editor popup menu** - lick the right mouse button after text selection to acces this menu. This menu is same as Edit sub-menu of the main menu;
7. **Task bar** - shows file names of all documents opened. You can switch between documents by clicking a button on the task bar;
8. **Status bar** - shows current status of the CNC Syntax Editor and other information such as:
 - Shows a short description of highlighted menu items.
 - Line No: Shows line and column numbers of insertion point.
 - CAP: Indicates that the Caps Lock key is on -- otherwise blank.
 - NUM: Indicates that the Num Lock key is on -- otherwise blank.
 - OVR: Indicates that the text being entered will overwrite existing text rather than being inserted. This is toggled on and off with the Insert key.
9. **Gutter** - displays editor lines numbering and uses for bookmarks and full line selection, described in the Edit menu section.




Fig.1 The main program window

Most CNC Syntax Editor menus have built-in hints. For example, when you move your mouse over a menu item, the hint is displayed on the status bar as shown on the screen shot.




Fig.2 Hint window

4.2 Configuring properties

Click the "Edit -> Properties..." menu to open the Properties dialog (Fig.1)




Fig.1. Options window. The "General" tab

Here you can customize appearance and behavior of the editor, colors of the syntax highlighting, enable or disable certain options etc.

Use tabs of the Options dialog box to customize the behavior of the editor.

General tab

Use the following editor options to control text handling in the editor. Check the option to enable it.

Auto indent mode - Positions the cursor under the first nonblank character of the preceding nonblank line when you press Enter.

Smart tab - Tabs to the first non-whitespace character in the preceding line. If Use Tab Character is enabled, this option is off.

Show line numbers - Show line numbers on the gutter. It's text lines numbering, not program numbering.

Backspace unindents - Aligns the insertion point to the previous indentation level (outdents it) when you press Backspace, if the cursor is on the first nonblank character of a line.

Use tab character - Inserts tab character. If disabled, inserts space characters. If Smart Tab is enabled, this option is off.

Group undo - Undoes your last editing command as well as any subsequent editing commands of the same type, if you press Alt+Backspace or choose Edit|Undo.

Cursor beyond EOF - Positions the cursor beyond the end-of-file character.

Cursor beyond EOL - Selection Beyond EOL.

Trim trailing blanks - Trim any blanks you might have at the end of a line.

Undo after save - enable/disable undo function after saving a program.

Right mouse click moves cursor - if you'll click right mouse button, then the editor cursor will move to a specified position.

Find text at cursor - Places the text at the cursor into the Text To Find list box in the Find Text dialog box when you choose Search|Find. When this option is disabled you must type in the search text, unless the Text To Find list box is blank, in which case the editor still inserts the text at the cursor.

Use syntax highlighting - Enables syntax highlighting. To set highlighting options, use the "Color scheme" page.

Disable dragging - Use the Key Mappings Options to specify key mapping modules and to enable or disable enhancement modules including what order to initialize them.

Show scroll hint - Use a hint over the scroll box while scrolling, which will display top line number.

Other options (when selected)

Tab stops - Set the character columns that the cursor will move to each time you press Tab. If each successive tab stop is not larger than its predecessor, you will receive an error.

Undo limit - undo function can store specified number of last changes only.

End of line symbol - Specify the type of line ending characters. CNC Syntax Editor will save all files with these character.

Display tab




Fig.2. Options window. The "Display" tab

Margin and gutter

Visible gutter - enable/disable visibility of the gutter at the left of an editor window.

Gutter color - gutter background color.

Margin position - maximum line length (in characters) at the right of an editor window.

Margin color - color of the margin.

Editor font/Editor font size - font type and font size of an editor window.

Editor color - an editor window background color.

Color scheme

Use the Color page of the Editor Options dialog box to specify how the different elements of your code appear in the editor (fig.3).




Fig.3. Options window. The "Color scheme" tab

You can specify foreground and background colors for anything listed in the "Item" list box. The sample editor shows how your settings will appear in the editor.

Scheme - Enables you to quickly configure the editor display using predefined color combinations. The sample code shows how your settings will appear in the editor.

!Default! - Displays reserved words in bold. Background is white. You can't delete this scheme.

Classic - Displays reserved words in white and code in yellow. Background is dark blue.

Twilight - Displays reserved words in light blue and code in white. Background is black.

Highlight - Same as default scheme. Displays reserved words in light blue and code in white. Background is white.

Item

Specifies syntax highlighting for a particular code element. You can choose from the Item list box or click the element in the sample editor.

The element options are:

Command - any G code;
Comment - any string in ();
Identifier - tool or tool selecting parameters etc;
Number - any digits with dot;
Parameter - any coordinates symbol after G code;
Reserved word - other characters (not numbers) after G code;
Sign - + or - before numbers;
Space - spaces between elements;
Unknown symbols - all others characters

As you change highlighting on various language elements, you can see the effect in the editor labeled Syntax Highlighting.

Foreground/Background Color - Sets the foreground and background colors for the selected code element. The foreground color changes automatically for each element you choose in the Item list box. It is not recommended to choose the same color for the foreground and the background, as you will be unable to read any text.

Text attributes - Specifies format attributes for the code element. The attribute options are: Bold, Italic, Underline.

Use the !default! scheme for:

- Displays the code element using default system colors for the foreground, background, or both.
- Unchecking either option restores the previously selected color or, if no color has been previously selected, sets the code element to the system color.

Note: To change the Windows system colors, use the Windows Control Panel.

5 Interface

5.1 Introduction

The menus of CNC Syntax Editor are located on the menu bar, which you can move at any position of the screen. The sub-menus of the main menu are File, Edit, Search, View, Tools, Window and Help. Each item in these menus is described in this section below. Some menu functions are also activated by pressing combinations of keys on the keyboard (called "Hotkeys" in this Help file), or by buttons on the toolbar. The Toolbar is located below the menu bar by default and you can move toolbar too.

Another way to access some edit menu functions is to click the right button of the mouse. See the help paragraphs on each function for more information. Hotkeys are described thus: "Ctrl+N" means that the user holds the Ctrl key down while simultaneously pressing the N key. The appropriate keyboard shortcuts and toolbar buttons are shown with each menu item.

5.2 Key mapping

Keystroke Action

UP Cursor Up

DOWN Cursor Down

LEFT Cursor Left

RIGHT Cursor Right

PAGE UP Page Up

PAGE DOWN Page Down

DELETE Delete Char Right

BACK Delete Char Left

Shift + BACK Delete Char Left

Shift + ENTER Enter

ENTER ENTER

TAB Tab

Ctrl + LEFT Jump Word Left

Ctrl + RIGHT Jump Word Right

Shift + DOWN Mark Down

Shift + UP Mark Up

Shift + LEFT Mark Left

Shift + RIGHT Mark Right

Shift + HOME Mark To Line Begin

Shift + END Mark To Line End

Shift + PAGE UP Mark Page Up

Shift + PAGE DOWN Mark Page Down

Ctrl + C Copy To Clipboard

Ctrl + X Cut To Clipboard

Ctrl + V Paste From Clipboard

Ctrl + Z Undo

Shift + Z Redo

Ctrl + F Show Search Dialog

Ctrl + R Show Replace Dialog

F3 Key Find Next

Ctrl + E Key Find Next

Ctrl + L Key Find Next

Ctrl + Y Delete Line

Ctrl + Shift + Y Delete To Line End

Ctrl + T Delete Word Right

Ctrl + N Insert Line

Ctrl + I Press Tab

Ctrl + A Select All

Shift + I Indent Block

Shift + U Outdent Block

Ctrl + Home Jump To File Begin

Ctrl + End Jump To File End

Ctrl + Down Scroll Down

Ctrl + Up Scroll Up

5.3 File menu




Fig.1. The file menu

New

Hotkey: Ctrl+N

This is used to create a new file. Once the file is created, it is automatically named "NoName1.ncp". As each new document is opened, the number in the title will increase: "NoName2.ncp", "NoName3.ncp", etc. Since CNC Syntax Editor is a multi-document editor, open documents will not be closed when a new one is opened.

Open

Hotkey: Ctrl+O

This will open an existing file. You will be asked for the file location. The file may take a short while to load. The default folder is the folder where CNC Syntax Editor had been installed.

Save

Hotkey: Ctrl+S

This saves the currently opened file in its current location. If the file is a new file, a dialog box appears allowing the user to choose a drive, folder and filename. This menu command only appears when there is one or more files opened.

Save as

This will save the currently opened file to a new location which you specify. This command only appears when there is a text file or files open.

Close

This will close the currently opened file. If file had been modified, then CNC Syntax Editor will ask you about saving.

Print

Hotkey: Ctrl+P

Choose a printer if more than one is available, and set its options. If you'll click a button on the toolbar, then CNC Syntax Editor prints the active document to the default printer without dialog

Page Setup

Allows the user to set options for printing the file. Paper size and orientation are set with the Print setup (fig.2).




Fig.2. The page setup

- **Units** - measure units of margins;
- **Margins frame** - sets the white space between the text and the page edges;
- **Mirror margins** - Set if margins should be mirrored (i.e. when printing 2-sided);
- **Line numbers** - Print line numbers;
- **Print line numbers in margin** - If this options is enabled then line numbers are printed in the left margin, otherwise left margin is increased by width of line number text;
- **Syntax print** - Highlight text;
- **Use colors** - Print in colors. Colours printed will depend upon the setup of your computer and printer;
- **Wrap lines** - Wrap text to margins.

Transfer to a CNC machine

CNC Syntax Editor uses the [DNC Precision](#) software by AGG Software for uploading files to a CNC machine. Please, refer DNC Precision manual for machines configuration.

Recent File List

This part of the File Menu, between Print Setup and Exit, is a list of recently opened documents. Clicking on one of these file names will open that document for editing

Exit

Closes CNC Syntax Editor and all open files. The user is given the opportunity to save any modified documents.

5.4 Edit menu




Fig.1. The Edit menu

Undo

Hotkey: Ctrl+Z

Right-click menu

Choose Undo in the editor to undo your most recent keystrokes or some mouse actions.

Using Undo in the editor

Undo can reinsert any characters you delete, delete any characters you insert, replace any characters you overwrite, or move your cursor back to its prior position. You can undo multiple successive actions by choosing Undo repeatedly. This removes your changes by "stepping back" through your actions and reverting to their previous state.

To specify an undo limit:

1. Choose Edit->Properties, and click the General page.
2. In the Undo limit box, enter a number to represent the maximum number of undos you want.

Note: You can undo an editing change after you save only if you check the Undo after save check box on the General tab.

If you undo a block operation, your file appears as it was before you executed the block operation.

Note: The Undo command does not change an option setting that affects more than one window.

Redo

Hotkey: Shift+Ctrl+Z

Choose Edit->Redo to reverse the effects of your most recent Undo. Redo has an effect only immediately after an Undo command.

Cut

Hotkey: Ctrl+X

Right-click menu

Choose Edit->Cut to remove the selected text from the editor from their current position and place them on the clipboard. Cut replaces the current clipboard contents with the selected item. To insert the contents of the clipboard elsewhere, choose [Edit->Paste](#). If you wish to use the Right-click menu for this function, move the mouse arrow on to the selected text, then click the right button of the mouse.

Copy

Hotkey: Ctrl+C

Right Click menu

Choose Edit->Copy (or right-click in the editor and choose Copy) to place an exact copy of the selected text, component, or menu on the clipboard and leave the original untouched. Copy replaces the current clipboard contents with the selected text. To insert the contents of the clipboard elsewhere, choose [Edit->Paste](#).

Paste

Hotkey: Ctrl+V

Right Click menu

Choose Edit->Paste to insert the contents of the clipboard into the active editor page.

Note: You can paste only text into the editor window.

When pasting into the editor window, the text is inserted at the current cursor position. You can also right-click in the editor and choose Paste from the context menu. You can paste the current contents of the clipboard as many times as you like until you cut or copy a new item onto the clipboard.

Delete

Delete key.

Right Click menu

Choose Edit->Delete to remove the selected text or component without placing a copy on the clipboard. Even though you cannot paste the deleted item, you can restore it by immediately choosing [Edit->Undo](#).

Delete is useful if you want to remove an item but you do not want to overwrite the contents of the clipboard. If you wish to use the Right-click menu for this function, move the mouse arrow on to the

selected text, then click the right button of the mouse.

Select all

Hotkey: Ctrl+A

Choose Edit->Select All to select all the text in the currently displayed file.

Goto line

Hotkey: Alt+G

This command allows to goto any line number. Choose Edit->Goto line and type a line number in the dialog box.

Delete empty lines

This will remove (delete) empty (without any text) lines from your file. You can restore it by immediately choosing [Edit->Undo](#).

Delete lines from/to

This will remove (delete) the specified range of lines from your file. When you click this menu item the dialog window will appear, which ask you about lines range. You can restore it by immediately choosing [Edit->Undo](#).

Delete comments

This will remove (delete) comments in () from your file, reducing file size. You can restore it by immediately choosing [Edit->Undo](#).

Delete non-printable characters

This will remove (delete) all characters with a decimal code from 0 to 32 and from 128 to 255 from your file. You can restore it by immediately choosing [Edit->Undo](#).

Insert file

Choose Edit->Insert file to insert the contents of a file into the active editor page. When you'll select this menu item then the dialog window will appear, when you should select a file name for inserting.

When inserting into the editor window, the text is inserted at the current cursor position. You can restore it by immediately choosing [Edit->Undo](#).

Properties

This will open properties [dialog window](#).

5.5 Search menu

Find

Hotkey: Ctrl+F

Choose Search->Find to display the Find Text dialog box (fig.1)




Fig.1 Find text dialog box

Find Text dialog box

Here you may specify text you want to locate and to set options that affect the search. Find locates the line of code containing the first occurrence of the string and highlights it.

Dialog box options

Text to find - Enter a search string or click the down arrow next to the input box to select from a list of previously entered search strings.

Options - Specified attributes for the search string

- **Case sensitive** - Differentiates uppercase from lowercase when performing a search;
- **Whole words only** - Searches for words only. (With this option off, the search string might be found within longer words.).

Direction - Direction to search, starting from the current cursor position

- **Forward** - From the current position to the end of the file. Forward is the default;
- **Backward** - From the current position to the beginning of the file.

Scope - How much of the file is searched

- **Global** - Searches the entire file in the direction specified by the Direction setting. Global is the default scope.
- **Selected text** - Searches only the selected text in the direction specified by the Direction setting. You can use the mouse or block commands to select a block of text.

Origin - Where the search starts

- **From cursor** - The search starts at the cursor's current position, and then proceeds either forward to the end of the scope, or backward to the beginning of the scope depending on the Direction setting. From cursor is the default Origin setting.
- **Entire scope** - The search covers either the entire block of selected text or the entire file (no matter where the cursor is in the file), depending upon the Scope options.

Find next

Hotkey: *F3*

Repeat the last search using the same options.

Replace

Hotkey: *Ctrl+R*

Choose Search->Replace to display the Replace Text dialog box (fig.2)




Fig.2 Replace text dialog box

Replace Text dialog box

Use this dialog box to specify text you want to search for and then replace with other text (or with nothing). Most components of the Replace Text dialog box are identical to those in the [Find Text](#) dialog box.

Text to find - Enter a search string. To select from a list of previously entered search strings, click the down arrow next to the input box.

Replace with - Enter the replacement string. To select from a list of previously entered search strings, click the down arrow next to the input box. To replace the text with nothing, leave this input box blank.

Prompt on replace - Prompts you before replacing each occurrence of the search string. When Prompt on replace is off, the Code editor automatically replaces the search string.

Replace All - Click Replace All to replace every occurrence of the search string. If you check Prompt on replace, the Confirm dialog box appears on each occurrence of the search string.

Next tool change

Hotkey: Ctrl+T

From the Search menu select Next tool change. The file will be scanned forwards for a tool change (M06), and the cursor will be re-positioned at that line.

Previous tool change

Hotkey: Ctrl+Shift+T

From the Search menu select Next tool change. The file will be scanned backwards for a tool change (M06), and the cursor will be re-positioned at that line.

5.6 Bookmarks

Toggle bookmarks

Right Click Menu

Hotkeys:

Shift+Ctrl+0 - Sets/replaces bookmark 0

Shift+Ctrl+1 - Sets/replaces bookmark 1

Shift+Ctrl+2 - Sets/replaces bookmark 2

Shift+Ctrl+3 - Sets/replaces bookmark 3

Shift+Ctrl+4 - Sets/replaces bookmark 4

Shift+Ctrl+5 - Sets/replaces bookmark 5

Shift+Ctrl+6 - Sets/replaces bookmark 6

Shift+Ctrl+7 - Sets/replaces bookmark 7

Shift+Ctrl+8 - Sets/replaces bookmark 8

Shift+Ctrl+9 - Sets/replaces bookmark 9

This command places a mark beside the line holding the cursor. The mark is visible as a rectangle with number on the gutter. If the line is already marked, "Toggle Bookmark" removes the bookmark.

Go to bookmarks

Right Click Menu

Hotkeys:

Ctrl+0 - Goes to bookmark 0

Ctrl+1 - Goes to bookmark 1

Ctrl+2 - Goes to bookmark 2

Ctrl+3 - Goes to bookmark 3

Ctrl+4 - Goes to bookmark 4

Ctrl+5 - Goes to bookmark 5

Ctrl+6 - Goes to bookmark 6

Ctrl+7 - Goes to bookmark 7

Ctrl+8 - Goes to bookmark 8

Ctrl+9 - Goes to bookmark 9

Moves the cursor position in the editor window to a bookmark.

5.7 View menu

Use the View menu commands to display or hide different elements of the environment and open windows that belong to the editor environment.

Non printable symbols - show/hide all characters with a code < 32 (Dec). Tabs, line feed etc.

Separate commands - this options enables visual splitting of NC commands in a line.

Choose View->Toolbars to show or hide the following in the editor environment:

- **Standard** - New, Open, Save, Save All, Open Project, Add file to Project, Remove file from project;
- **Tools** - Code repository, Lines numbering, Shift, Scale, Mirror, Exchange axes, Add and Remove spaces;
- **Task bar** - this bar displays titles of all documents opened in the editor environment;
- **Status bar** - this bar displays status of the editor environment.

Check the items you want to display and uncheck those you want to hide. The toolbars provide icons as shortcuts for actions you can perform.

Locked scrolling - you can open two windows and enable this options. In this case if you'll scroll first window, then second window will be scrolled too and vice versa.

5.8 Tools Menu

5.8.1 Code repository

The Code repository (Tools->Code repository) (fig.1) provides templates for new projects and blocks of a most uses code. The Repository is maintained in Repository directory (under directory, where CNC Syntax Editor had been installed), that contains a files with all items in the Repository. It is not designed to save large files, but segments of code up to 16 KB.




Fig.1 Code repository dialog box

Choose Tools->Repository or click on the Code repository button  to display the Object Repository dialog box.

Items description

1. Sorting tool bar - allows you to select a sort order of the item list #5.
2. Buttons toolbar - contains buttons for quick access to repository functions:

-  Previous - select previous item in the item list;
-  Next - select next item in the item list;
-  New - adds new item into the item list. After a click on the button CNC Syntax Editor will add new item to the list and will allow you to change an item description. For changing the item description you should click an item name twice (click-pause-click);
-  Save - saves modified item;
-  Delete - deletes current selected item;
-  Copy - copy a content of the current item to the clipboard;
-  Paste - paste content of the clipboard to the repository window.

Search toolbar - allows you search a text within all item in the item list. Type any text and click the

Search  button. CNC Syntax Editor will try to find an occurrence of searching text. Click the Search button again for searching a next occurrence. You can use wildcard characters ? and * while searching, where ? is any one character and * is a group of one or more characters.

3. The Repository editor window - here you can see or edit your repository items. The Repository editor window uses same syntax and editing options as other editor windows;
4. The item list - this list contains names of all items in the Repository. Click any item in the list for selecting the item and load their content to the Repository editor.

Adding a new code item:

1. Click the New button to add new item into the Repository;
2. Type your item name;
2. Type or paste your code into the Repository editor window;
4. Click the Save button.

Inserting a code item into a CNC file:

1. Click the name of the code item in the item list;
2. Click the Copy button;
3. Minimize or close Code Store;
4. Press Ctrl+V, click a toolbar button or right-click the mouse and select the Paste menu ite.

Removing a code item:

Click the name of the item in the item list and click the Delete button.

Searching all code items for a text:

1. Type your text;
2. Click the Search button.

5.8.2 Lines numbering

Renumber lines

This feature will add or remove the line numbers. Standard CNC line numbers with the format of Nnnnn are used. When adding (numbering) the lines you have the choice of numbering each line with its true line number, or to start the count at a certain number and increment by another number. To add the line numbers click "Renumber lines". A dialog window will appear (fig.1).

Parameters

Please, specify the lines range: All lines

From: 1 to: 129

Start/max line number: 1 999999

Step: 1

Renumber lines without numbering only

Renumber lines with comments

Renumber lines with skipped blocks

Cycle numbering

Skip lines starting with: ()

Numbers

Decimals: 4

Trailing decimal point is required

Trailing zeros for numbers

Leading zero for numbers

OK Cancel

Fig.1 Renumber lines dialog box

This dialog allows the user to choose the section of code to process. The defaults are "First line" and "Last line" of a file. To change these numbers, click the check box and enter the required line number into the window. Please note that the line numbers in this box are not block numbers (Nnnnn), but are document line numbers.

The Status Bar shows the document number of the line where the cursor is located. The section of the file to be processed may also be chosen by selection.

Start line number - It's the number that will begin the sequence on "First Line". Integer numbers only can be entered.

Step - Enter the increment amount. Integer numbers only.

Renumber lines without numbering only - Checking this box will add a block number to a line of code that is currently without numbering. Lines beginning with N,O,P, and any non-alpha character will be ignored.

Leading zero for numbers - CNC Syntax Editor will add leading zero for lines. For example: last line number is 9999 and first line number is 10, then CNC Syntax Editor will add the following text to the first line: N0010.

Remove line numbers

Removes all block numbers from the current file.

5.8.3 Shift/Scale/Mirror

Shift

This command allows the user to add or subtract an amount to/from selected axis (address) value from a part of the file or whole file. Use the "Shift value" dialog box to select the part of the file for processing. (fig.1).

Fig.1 Shift value dialog box

Check the axis (adresse) to be processed and enter a positive or negative amount in the "Increment" field. Then click "OK" button.

Before processing a file the CNC Syntax Editor will offer you to create a backup copy of the current file.

Scale

Use this dialog box to specify a scale value and one or more code addresses by a specific factor. An ideal use for this command is to convert programs from inch to metric, and vice versa. Most components of the Scale dialog box are identical to those in the Shift dialog box.

Factor - scaling value.

Mirror

Mirror changes all incidences of one or more code values from positive to negative, and vice versa. An option to change arc cutting direction and tool radius compensation direction is provided. Most components of the Mirror dialog box are identical to those in the Shift dialog box. When "Mirror" is selected, you may change the arc cutting direction by checking the "G02<-->G03" checkbox, and switch cutter diameter compensation between right and left by checking the "G41<-->G42" checkbox.

Note:

- All of the above commands may be processed throughout all of the file, or a specified part of the file by using the "From" and "To" fields.
- Before processing a file the CNC Syntax Editor will offer you to create a backup copy of the current file.

5.8.4 Exchange axes

This function allows the user to exchange the values of one coordinate address to another (fig.1). Most components of the Exchange axes dialog box are identical to those in the [Shift](#) dialog box.




Fig.1 Exchange axes dialog box

Choose the axes you wish to exchange from the "Exchange axes", and click "OK". All of the incidences of the first address in a line will be changed to the second, and vice versa. You can exchange values between any axes. Just select "Custom axes" item from the "Exchange axes" group and type your axes names.

Note:

- All of the above commands may be processed throughout all of the file, or a specified part of the file by using the "From" and "To" fields.
- Before processing a file the CNC Syntax Editor will offer you to create a backup copy of the current file.

5.8.5 Add and remove spaces

This feature can either insert spaces into your file to make it easier to read, or it can remove spaces from your file to save file space. "Add Spaces" will add a space before every letter after G code. "Remove Spaces" will simply remove every space in the file. You can add spaces on screen only. Use the [Separate commands](#) options.




Fig.1 Add and remove spaces dialog box

Note:

- All of the above commands may be processed throughout all of the file, or a specified part of the file by using the "From" and "To" fields.
- Before processing a file the CNC Syntax Editor will offer you to create a backup copy of the current file.

5.8.6 Compare file with WinDiff

WinDiff is a File Compare application that is provided by Microsoft. WinDiff has its own Help, however, the following instructions will get you started.

When you choose WinDiff from the Tools menu, the Open file dialog appears. Enter the names of the files you wish to compare, or use the browse button to search through your folders, or choose from recently compared files by using the down arrow button.

5.8.7 Change characters case

Uppercase

From the Tools2 menu select Uppercase. The all characters in the file will be converted to uppercase.

Lowercase

From the Tools2 menu select Lowercase. The all characters in the file will be converted to lowercase.

5.8.8 Adjusting spindle speed and feed rate

Adjust spindle speed

The Adjust spindle speed command is used to quickly change the spindle speeds in a CNC Program. If text is selected, it will add change the spindle speeds in the selected text. If no text is selected, the command will change the spindle speeds of either the entire file or the current line, depending on the user's preference. To change spindle speeds specify following parameters:

New value - type a new spindle speed value as a specific percent (100% - current value)

Minimum - Specify a value to make sure spindle speeds don't go below a minimum value.

Maximum - Specify a value to make sure spindle speeds don't go above a maximum value.

Decimals - Specify number of decimals to the right of the decimal point into this field.

Adjust feed rate

The Adjust feed rate command is used to quickly change the feed rates in a CNC Program. If text is selected, it will add change the feed rates in the selected text. If no text is selected, the command will change the feed rates of either the entire file or the current line, depending on the user's preference. To change feed rates specify following parameters:

New value - type a new feed rate as a specific percent (100% - current value)

Minimum - Specify a value to make sure feed rates don't go below a minimum value.

Maximum - Specify a value to make sure feed rates don't go above a maximum value.

Decimals - Specify number of decimals to the right of the decimal point into this field.

5.8.9 Rotate

The Rotation function can be used to rotate all the coordinates in your file around a particular center point (fig.1) Rotation can occur in any plane (XY, XZ, or YZ) and can automatically sense the status of G90 and G91 in your program. When rotating in the XY plane, the X, Y values are rotated, and the Z value are not affected. Similarly, when rotating in the XZ plane, the X, Z values are rotated, and the Y value are not, (etc.). The program rotation function does not work for 3-axis circular moves (spherical interpolation) where all 3 axes are programmed in the same block. In this case, only the two axes selected are rotated, and the 3rd axis is not affected.




Fig.1 Rotate program

Axes to rotate - Select axes to rotate (XY, XZ).

Angle - Enter the angle of rotation by degrees in this field.

Centre of rotation - Enter the co-ordinates of the center of the rotation in these axes (X - first axis, Y - second axis).

Decimals - Specify number of decimals to the right of the decimal point into this field.

Sense to G90/G91 - Check this field when the program should automatically sense the status of G90 and G91 in your program.

5.8.10 Find XYZ ranges

The Find XYZ ranges function will scan your program for the maximum and minimum values for each axis. This function does not change the contents of your text box, but only displays its maximum and minimum values. In addition to axis motions, such as X,Y, and Z, you can also see Max/Min values of spindle speeds and feed rates, ABC axes and total dimensions of your piece.

Value	Minimum	Maximum
<u>X/Y/Z ranges</u>		
X	-4,7657	0
Y	-0,6502	0,6502
Z	-0,3	3
<u>A/B/C ranges</u>		
A	???	???
B	???	???
C	0	36
<u>F/S ranges</u>		
F	0	20
S	0	800
<u>Dimensions</u>		
Length X	4,7657	
Width Y	1,3004	
Height Z	3,3	

Fig.1 Find XYZ ranges

5.9 Windows menu

CNC Syntax Editor includes a Window menu item that contains Tile, Cascade, and Arrange Icons commands to offer users an easy way to arrange their open documents in the client area of the frame window.

Cascade

Arranges all open, non-minimized windows in a cascading stack. Click on the title bar of any window to make that window active and fully visible.

Tile horizontally or Vertically

Arranges all open, non-minimized windows so that an equal portion of each window is visible. When tiled horizontally, the windows are arranged up and down the screen. When tiled vertically, they are across the screen.

Arrange Icons

If you do not wish to include a window or windows in a tiled or cascaded arrangement, minimize that window and it will appear as an icon. This menu command arranges icons in rows at the bottom of the screen. These icons cannot be seen if any document window is maximized.

List of the open document windows

The Window menu item contains a list of the open document windows, which lets users quickly switch among them. (The window that currently has focus appears in the list with a check mark next to it.)